Your mobile



This product meets applicable national SAR limits of 2.0 W/kg. The ific maximum SAR values can be found on page 16 of this user When carrying the product or using it while worn on your body,

either use an approved accessory such as a holster or otherwise ain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be ransmitting even if you are not making a phone call.



Prolonged exposure to music at full volume on the music purposition, the listener's hearing. Set your phone volume safely. Use only headpho Prolonged exposure to music at full volume on the music player may damage

ALCATELONE LOUCH (1) Depending on your network operator.

Navigation key

Confirm an option (press the middle of the key) Access "Change timing" (long keypress in idle screen)

Pick up

Send a call Access call memory (Redial) (short keypress)

Switch on/Switch off the telephone (long keypress) End call

Return to the idle screen

Left softker

Access your voicemail (long keypress)

In edit mode

- Short keypress: access the language list

- Long keypress; enter zero

From idle screen - Short keypress:

- Long keypress: lock/unlock the keypad In edit mode:

- Short keypress: change input methods

- Long keypress: access the Symbols table

From idle screen

- Short keypress: # - Long keypress: activate/deactivate the vibrator In edit mode:

- Short keypress: - (space)

- Long keypress: add a word

From idle screen

- Short keypress: dial '5'

- Long keypress: switch on/off the torch

Idle screen icons

Battery charge level.

Vibration alert: your phone vibrates, but neither rings no

Call forwarding activated: your calls are forwarded.

Alarm clock programmed

Voicemail message arrived

FM radio is on

Unanswered calls

WAP alerts (I). GPRS attached

GPRS connecting.

Line switching (1): indicates the selected line

Level of network recention

Silence mode: your phone neither rings, beeps nor vibrates.

Message unread

Keypad locked.

Getting started

Removing and installing the back cover



Installing and removing the battery







Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card. press it and slide it out.

Charging the battery



Connect the battery charger to your phone and mains socket respectively

The charging may take about 20 minutes to start if the battery is flat.

Be careful not to force the plug into the socket. Make sure the battery is correctly inserted before connecting the

charger The mains socket must be near to the phone and easily accessible

(avoid electric extension cables). When using your telephone for the first time, charge the hattery fully (approximately 3 hours). You are advised to fully charge the battery 3.3 Receiving a call

To reduce power consumption and energy waste, when battery is and then hang up using the **key. fully charged, disconnect your charger from the plug; reduce the



backlight time, etc.

The charge is complete when the animation stops.

Power on your phone

Hold down the * key until the phone powers on.

2.3 Power off your phone

Hold down the ** key from the idle screen.

Calls

Making a call

Dial the desired number then press the — key (send key) to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the - key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the — key (send key) to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking

3.2 Calling your voicemail (1)

To access your voicemail, hold down the | • key.

When you receive an incoming call, press the — key (send key) to talk

3.4 Available functions during the call

During a call, you can use your directory, short messages, etc. without losing your correspondent.

(I) Contact your network operator to check service availability.

Call register 😝 5



You may go to "Settings" and select "Call register" menu, below 5.1 Consulting your directory options are available:

4.1 Call memory

from the idle screen 4.2 My numbers

your voicemail and confirm by pressing . Your telephone number is usually written on your SIM card.

4.3 Billing (1) You can access different items with this option: Amount, Duration, GPRS counter, Beep duration.

4.4 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Auto redial...

4.5 Call control (1)

(I) Depending on your network operator.

English - CIB22VDALAAA

The menu serves you the dual purposes of cost monitoring and controlling during a call by the settings of "By cost" and "By duration".

To access the **directory** from the idle screen, press the key and select the 🔝 icon from the menu.

"Options" softkey, select "Add contact" then

Type in or modify your telephone number or the number to access

can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to 9,3 access all the messaging options. You can save your messages that you send often to "Drafts".



Specific letters (accent) will increase the size of the SMS. this may cause multiple SMS to be sent to your recipient. 9.4 Fake call

Access WAP options: Homepage, Bookmarks, Recent pages, Offline pages, Go to URL, Push inbox and Profiles.

You can access your call memory by pressing the — key (send key) 5.2 Creating a file

Select the directory in which you wish to create a file, press

Messages

6.1 Create message

From the main menu select "Messages" to create text message. You Your mobile phone has a built-in alarm clock with a snooze feature.

WAP.....

Settings

(I) Depending on your network operato

From the main menu, select the icon menu and select the function memo", then "New record". of your choice in order to customise your telephone Color, Display, Clock, Keys, Call register (1), More settings.

Tools

9.1 Calendar

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc Days with events entered will be marked in color

Calculator

Hold down the # key to get the decimal point. Confirm with the key or the left softkey.

Protect yourself from annoying situations with the "Fake Call". In this menu, you can set "Caller name/number", "Call time" "Ringtone" and "Image". When the timer reaches the phone will ring and display like receiving a real phone call. Press — (Left softkey) 10.2 FM radio key, pretend answering a call, the screen will display just like have an ongoing call. Press ** key, pretend reject the call, the call will terminate automatically.

9.5 Converter

Unit converter and Currency converter

See details info on Page 7

This feature enables you to record a call by selecting "Sound recorder" while communicating. To record a sound, select "Voice

9.7 Memory status

9.8 My shortcuts

It will indicate how much space is used and how much is currently free on your phone.

shortcuts:select "Add" if you want to create a quick access to functions, You can select an image as wallpaper, ON/OFF screen or contact ID. numbers, or wap bookmarks, etc.

99 Torch

To light in darkness, you may activate "Torch" by below operations In idle screen, long keypress 5⁵⁴⁷ key to activate the Torch light; select **off** or go back to idle screen then long keypress 5 key to deactivate it.

Your Alcatel phone may include some games. You could set background music and vibration alert.

Your phone is equipped with an FM radio (1) with RDS functionality. You environments. can use the application as a traditional FM radio with automatic tuning and saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

(1) The quality of the radio depends on the coverage of the radio station in that particular area.

File manager.....

You will have an access to all audio and visual files stored in phone in

II.I My audios Choose an audio for an incoming call, a message alert, power on/off

ringtone or contact ID

Access the shortcuts already programmed. To programme new II.2 My images

11.3 Unknown files Store files of unsupported format.

11.4 Memory status

Services 🚉

Contact your network operator to check service availability.

Profiles......

With this menu, you may personalise ringtones for different events and

Latin input mode.....

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.
- Predictive with the Zi mode: this mode speeds up the writing of your text. Write the word by pressing a key between and 2 and 9 Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following keys:

 8π , 6π , 6π = Too -> 6π -> tomorrow - O+ key in edit mode Short keypress: access the language list

Long keypress: enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2011 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

For more information about how to use the phone, please go to www.alcatelonetouch.com to download complete user manual (English version only). Moreover, from the website you can also consult FAQ (English version only).

12

We recommend that you read this chapter carefully before using your phone. The Over 55°C the legibility of the phone's display may be impaired, though this is manufacturer disclaims any liability for damage, which may result as a consequence of temporary and not serious. improper use or use contrary to the instructions contained herein.

TRAFFIC SAFETY:

a real risk, even when the hands-free kit is used (car kit, headset...), drivers are

Do not drop, throw or bend your mobile phone. ested to refrain from using their mobile when the vehicle is not parked.

radio. Using a headphone can be dangerous and forbidden in some areas.

- the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that other chargers or batteries. there is no problem: do not place your phone on top of the dashboard or within an airbag deployment
- check with your car dealer or the car manufacturer to make sure that the

dashboard is adequately shielded from mobile phone RF energy. CONDITIONS OF LISE

Switch the phone off before boarding an aircraft.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all - Do not play or use a flashing-lights feature if you are tired or need sleep. signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any notentially explosive atmosphere

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any, To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage. Do not let children use the phone and/or play with the telephone and accessories

When replacing the cover please note that your phone may contain substances that disorders

could create an allergic reaction. Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental • PRIVACY: Safety and use Do not allow your phone to be exposed to adverse weatner or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to +55°C.

> Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourse

Do not paint it.

Mobile Limited and its affiliates and are compatible with your phone model. TCT • BATTERY:

Remember to make back-up copies or keep a written record of all important. Observe the following precautions for battery use information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing - Do not puncture disassemble or cause a short-circuit in a battery. lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your Batteries must be disposed of in accordance with locally applicable envir You are advised to switch off the telephone from time to to me to optimise its doctor before playing video games on your phone or enabling a flashing-lights feature regulations, Only use the battery for the purpose for which it was designed. Never use Tests for SAR are conducted using standard operating positions with the device.

As mobile devices offer a range of functions, they can be used in positions other than the Declaration of Conformity for your telephone can be obtained.

Parents should monitor their children's use of video games or other features that affiliates Switch the phone off when you are in health care facilities, except in designated areas. incorporate flashing lights on the phones. All persons should discontinue use and As with many other types of equipment now in regular use, mobile telephones can consult a doctor if any of the following symptoms occur: convulsion, eye or muscle interfere with other electrical or electronic devices, or equipment using radio twitching, loss of awareness, involuntary movements, or disorientation. To limit the elihood of such symptoms, please take the following safety precautions:

- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for In European Union countries: several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal



corrosion oxidation

the listener's hearing. Set your phone volume safely. Use only headphones nended by TCT Mobile Limited and its affiliates

voices of other people or any of their personal attributes and duplicate or distribute, not work in another jurisdiction. They should be used for this purpose only. them, as this may be considered to be an invasion of privacy. It is the user's sole • RADIO WAVES: responsibility to ensure that prior authorisation be obtained if necessary in order to When driving, do not use your phone and headphone to listen to music or to the Use only batteries, battery chargers, and accessories which are recommended by TCT disclaim any liability which may result from the improper use of the mobile phone.

When switched on, your phone emits electromagnetic waves that can interfere with Mobile Limited and its affiliates disclaim any liability for damage caused by the use of Before removing the battery from your phone, please make sure that the phone is WAVES switched off

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C.

damaged batteries or those not recommended by TCT Mobile Limited and/or its transmitting at its highest certified power level in all tested frequency bands. The against your ear. In such circumstances the device will be compliant with the guidelines through Our website: www.alcatelonetouch.com

This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of equipment

They will then be recycled, preventing substances being disposed of in the

These collection points are accessible free of charge

nent, so that their components can be reused

All products with this sign must be brought to these collection points. In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if you jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT Prolonged exposure to music at full volume on the music player may damage

TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

CHARGERS

Mains powered chargers will operate within the temperature range of 0°C to 40°C. stated above. This is because, for purposes of system efficiency and to minimize other jurisdiction(s) where you will use your mobile phone regarding taking

The chargers designed for your mobile phone meet with the standard for safety of interference on the network, the operating power of your mobile device is tographs and recording sounds with your mobile telephone. Pursuant to such laws information technology equipment and office equipment use. Due to different automatically decreased when full power is not needed for the call. The lower the lations, it may be strictly forbidden to take photographs and/or to record the applicable electrical specifications, a charger you purchased in one jurisdiction may power output of the device, the lower its SAR value.

1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURETO RADIO indicate the need for any special precautions for the use of mobile devices. They

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the can easily do so by limiting your usage or simply using a hands-free kit to keep the limits for exposure to radio waves (radio frequency electromagnetic fields), device away from the head and body. recommended by international guidelines. The guidelines were developed by an For more information you can go to www.alcatelonetouch.com independent scientific organization (ICNIRP) and include a substantial safety margin Additional information about electromagnetic fields and public health are available on designed to assure the safety of all persons, regardless of age and health.

Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg

highest SAR values under the ICNIRP guidelines for this device model are:

Assimum SAR for this model and conditions under which it was recorded

Head SAR	GSM 900	1.3 W/kg
Body-worn SAR	GSM 900	1.0 W/kg

During use, the actual SAR values for this device are usually well below the values General information

Internet address: www.alcatelonetouch.com

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any positioned at least this distance away from the body. If you are not using an approved questions you may have.

accessory ensure that whatever product is used is free of any metal and that it

An electronic version of this user guide is available in English and other languages according to availability on our server: www.alcatelonetouch.com

recommend that if you are interested in further reducing your exposure then you Your telephone is a transceiver that operates on GSM networks with 900 and 1800 MHz hands

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of

that whatever product is used is free of any metal and that it positions the phone at Protection against theft (1)

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering # # 0.6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen This number allows your mobile telephone to be blocked preventing a third person from using it even with a different SIM card

Disclaimer

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

Telephone warranty

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your 3) Modification or repair performed by individuals not authorised by • You are advised to switch off the telephone from time to time to original invoice

Batteries (2) and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories are entitled to a one (I) month warranty for the same defect. Repair or In no event shall TCT Mobile Limited or any of its affiliates be liable for replacement may be carried out using reconditioned components indirect, incidental or consequential damages of any nature whatsoever, My phone has not responded for several minutes offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any other

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

conversation time standby time, and total service life, will depend

on the conditions of use and network configuration. Batteries being

considered expendable supplies, the specifications state that you

should obtain optimal performance for your phone during the first

six months after purchase and for approximately 200 more

(I) The warranty period may vary depending on your country. (2) The life of a rechargeable mobile phone battery in terms of

- 1) Non-compliance with the instructions for use or installation, or with **Troubleshooting......** technical and safety standards applicable in the geographical area where your phone is used
- 2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited.
- TCT Mobile Limited or its affiliates or your vendor. 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or • You are advised to fully charge (iii) the battery for optimal

foods, chemical products, download of files, crash, high voltage,

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty

• Check the battery charge level provided by your country or jurisdiction.

including but not limited commercial or financial loss or damage, loss of • Press the ** key data or loss of image to the full extent those damages can be disclaimed • Remove the battery and re-insert it, then switch the phone back on

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

Before contacting the aftersales department, you are advised to follow

- optimise its performance
- operation
- · Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.

and carry out the following checks:

My mobile phone will not switch on Press - until the screen comes on

- · Check the battery contacts, remove and reinstall your battery, then turn your telephone back on

My screen is difficult to read

- Clean your screen
- Use your mobile phone in accordance with the recommended conditions of use

My mobile phone turns off by itself

- Check that your keypad is locked when you are not using your mobile
- Check the battery charge level

My mobile phone has a low level of autonomy

- hours) · After a partial charge, the battery level indicator may not be exact. · Make sure your mobile phone is connected to a network, and that the
- Wait for at least 20 minutes after removing the charger to obtain an exact indication

My mobile phone will not charge properly

- Make sure that your battery is not completely discharged; If the battery is flat, it may take around 20 minutes to display the battery Unable to receive incoming calls charger indicator on the screen
- Make sure charging is carried out under normal conditions (0°C-+40°C)
- Make sure your battery is inserted. It must be inserted before plugging in the charge
- Make sure you are using an Alcatel battery and charger in the box When abroad, check that the electrical current is compatible

My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

SIM card error

- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V or 18V compatible; the old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

- Make sure you respected the complete charge timing (minimum 3 Make sure you have dialled a valid number and press the key
 - For international calls check the country and area codes
 - network is not overloaded or unavailable Check your subscription status with your operator (credit, SIM card valid etc)

Body-worn SAR testing has been carried out at a separation distance of 1.5 cm. To

meet RF exposure guidelines during body-worn operation, the device should be

Your telephone is equipped with a built-in antenna. For optimal operation, you shou

when used with headset or USB data cable. If you are using another accessory ensure

positions the phone the indicated distance away from the body.

the following site: http://www.who.int/peh-emf

avoid touching it or degrading it.

least 1.5cm away from the body.

7ICOTDOTATION and/or its Affiliates.

·LICENCES

The World Health Organization has stated that present scientific information

Make sure you have not barred outgoing calls

- Make sure your mobile phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit SIM card valid, etc.)
- Make sure you have not forwarded incoming calls
- Make sure that you have not barred certain calls

The caller's name does not appear when a call is received

- Check that you have subscribed to this service with your operator
- Your caller has concealed his/her number

The sound quality of the calls is not optimal

- You can adjust the volume during a call by means of the key
- Check the network strength

I am unable to use the features described in the manual

- · Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number is not

- · Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a
 Switch on the backlight upon request. foreign country

I am unable to create a file in my directory

 Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or personal directories)

- Contact your network operator to check service availability
- "My numbers"

The icon is displayed on my standby screen

· You have saved too many short messages on your SIM card; delete

" No service" is displayed

You are outside of the network coverage area

· Contact your network operator to obtain the PUK code (Personal

My mobile phone is frozen, can't power on

Remove your battery remove your SIM card then reinstall them to

power on again, if still does not work: Hold down # key and press Power on/off key for a while to reset the

All user phone data: contacts, messages and files will be lost

Make sure you follow the complete charge time (minimum 3 hours) After a partial charge the battery level indicator may not be exact.

exact indication

22

17

23

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

(I) Contact your network operator for service availability.

My callers are unable to leave messages on my voicemail

I cannot access my voicemail

- Make sure your operator's voicemail number is correctly entered in
- Try later if the network is busy

some of them or archive them in the product memory

I have already entered 3 incorrect PIN codes

Unblocking Key)

- Make sure your battery is not completely used up or damaged;

How to make your battery last longer

Wait for at least 20 minutes after removing the charger to obtain an